

ITEMQTY.PART NUMBERDESCRIPTION110373901ASSEMBLY, FRAME210373903ASSEMBLY, WEAR STRIP AND BELT GUIDE310373904ASSEMBLY, SAW BLADE DRIVE410373906ASSEMBLY, LOWER CHAIN GUARD510373907ASSEMBLY, AIR NOZZLE610373908ELECTRICAL CONNECTIONS (MANUAL COB SAW)	2			1
2       1       0373903       ASSEMBLY, WEAR STRIP AND BELT GUIDE         3       1       0373904       ASSEMBLY, SAW BLADE DRIVE         4       1       0373906       ASSEMBLY, LOWER CHAIN GUARD         5       1       0373907       ASSEMBLY, AIR NOZZLE	ITEM	QTY.	QTY. PART NUMBER	DESCRIPTION
3       1       0373904       ASSEMBLY, SAW BLADE DRIVE         4       1       0373906       ASSEMBLY, LOWER CHAIN GUARD         5       1       0373907       ASSEMBLY, AIR NOZZLE	1	1	1 0373901	ASSEMBLY, FRAME
4       1       0373906       ASSEMBLY, LOWER CHAIN GUARD         5       1       0373907       ASSEMBLY, AIR NOZZLE	2	1	1 0373903	ASSEMBLY, WEAR STRIP AND BELT GUIDE
5       1       0373907       ASSEMBLY, AIR NOZZLE	3	1	1 0373904	ASSEMBLY, SAW BLADE DRIVE
	4	1	1 0373906	ASSEMBLY, LOWER CHAIN GUARD
6 1 0373908 ELECTRICAL CONNECTIONS (MANUAL COB SAW)	5	1	1 0373907	ASSEMBLY, AIR NOZZLE
	6	1	1 0373908	ELECTRICAL CONNECTIONS (MANUAL COB SAW)
7 1 0373942 ASSEMBLY, UPPER BLADE GUARD	7	1	1 0373942	ASSEMBLY, UPPER BLADE GUARD
8 1 0373943 ASSEMBLY, DISCHARGE CHUTE	8	1	1 0373943	ASSEMBLY, DISCHARGE CHUTE
9       1       0373905       ASSEMBLY, BELT DRIVE	9	1	1 0373905	ASSEMBLY, BELT DRIVE

